



1st/2nd generation Laser-Produced Plasma source system for HVM EUV lithography

Hakaru Mizoguchi*1, Tamotsu Abe, Yukio Watanabe, Takanobu Ishihara, Takeshi Ohta, Tsukasa Hori, Tatsuya Yanagida, Hitoshi Nagano, Takayuki Yabu, Shinji Nagai, Georg Soumagne, Akihiko Kurosu, Krzysztof M. Nowak, Takashi Suganuma, Masato Moriya, Kouji Kakizaki, Akira Sumitani, Hidenobu Kameda*1, Hiroaki Nakarai*1, Junichi Fujimoto

****1 Gigaphoton Ltd. :400 Yokokura shinden, Oyama, Tochigi, Japan
Komatsu Ltd. : 3-25-1 Shinomiya, Hiratsuka, Japan***



Outline

1. Introduction

2. Engineering Test source

- **1st Generation (ETS) device: System experiment**
 - Operation Data
- **10Hz device: Critical issue experiment**
 - Vaporization experiment
 - Ionization experiment
 - Magnetic mitigation
 - Pre-pulse and high CE

3. HVM EUV light source

- **Product roadmap**
- **2nd Generation device: Development status**
 - Configuration
 - Latest status

4. Summary



Outline

1. Introduction

2. Engineering Test source

- **1st Generation (ETS) device: System experiment**
 - Operation Data
- **10Hz device: Critical issue experiment**
 - Vaporization experiment
 - Ionization experiment
 - Magnetic mitigation
 - Pre-pulse and high CE

3. HVM EUV light source



- Product roadmap
- **2nd Generation device: Development status**
 - Configuration
 - Latest status

4. Summary

EUV sources

LPP: CO₂ laser and Sn source

- ✓ High power pulsed CO₂ laser
- ✓ Magnetic field plasma mitigation
- ✓ Pre-Pulse plasma technology



Type	LPP		DPP
Maker	Gigaphoton	Company A	Company B
Size	Large	Very Large	Small
Power (at present)	104W/21W	90W/20W	34W/34W
Plasma	No electrode	No electrode	Disc electrode
Mitigation	Pre pulse + Magnet	Gas	Gas + mechanical shutter
Life limitation	(several 1000 hr)	Several 10 hr	Several 10 hr
Bottle neck	-	Mirror	Electrode/Mirror
Remark	<ul style="list-style-type: none"> • Theoretically no limit • Engineering works still to be done 	<ul style="list-style-type: none"> • Trade off of power and lifetime 	<ul style="list-style-type: none"> • Trade off of power and lifetime • Trade off of power and beam quality



Outline

1. Introduction

2. Engineering Test source

- **1st Generation (ETS) device: System experiment**
 - Operation Data
- **10Hz device: Critical issue experiment**
 - Vaporization experiment
 - Ionization experiment
 - Magnetic mitigation
 - Pre-pulse and high CE

3. HVM EUV light source




- Product roadmap
- **2nd Generation device: Development status**
 - Configuration
 - Latest status

4. Summary

ETS system configuration


System layout

■ Laser System



Laser Power: 13 kW
Pulse Width: 20 ns
Repetition Rate: 100 kHz
Pulse energy stability : 2% (3s, 500 pulses)

■ EUV chamber




System operation Data (ETS device)

	SPIE 2010 (Feb.2010)	EUV Symposium (Oct.2010)	Latest Data (Feb,2011)
EUV power (@ I/F)	69 W	104 W	42 W
EUV power (clean @ I/F)	33 W	50 W	20 W
Duty cycle	20 %	20 %	5%
Max. non stop op. time	>1 hr	<1 hr	>7 hr
Average CE	2.3 %	2.5 %	2.1%
Dose stability :simulation	(+/- 0.15%)		-
Droplet diameter	60μm	60μm	30μm
CO₂ laser power	5.6 kW	7.9 kW	3.6kW

Droplet generator lifetime improvement ($\phi 30 \mu\text{m}$)


- **Operation time improved from <1 hour to >7 hours**



System operation result on ETS

➤ Long time system operation demonstrated

- Operation duration: **7 hours**
- Droplet **30 μm diameter**
- Full repetition rate: **100 kHz**
- In burst clean power: **20W (average)**
25W (max)



Conditions;

Control: Droplet position control ON, EUV energy control OFF
 CO₂ laser = 3.6kW @ 100kHz
 Duty=5% (50msecON, 950msecOFF)


Conclusion of ETS device experiment

“ETS experiment clarified 3 key challenges are essential”

- ✓ **CE (Conversion Efficiency) improvement**
- ✓ **Debris mitigation = Stability and size of droplets**
- ✓ **CO₂ laser load = power x duty**



Droplet generator





Outline

1. Introduction

2. Engineering Test source

- **1st Generation (ETS) device: System experiment**
 - Operation Data
- **10Hz device: Critical issue experiment**
 - Vaporization experiment
 - Ionization experiment
 - Magnetic mitigation
 - Pre-pulse and high CE

3. HVM EUV light source


- Product roadmap
- **2nd Generation device: Development status**
 - Configuration
 - Latest status

4. Summary

Collector mirror protect Concept


All Sn atoms should be ionized.

- ① Magnet field is effective for guiding ions not to going to mirror
- ② All Sn fragments and atoms are needed to be ionized




Critical issue investigation with 10Hz device

- *Double pulse optimization*
- *Debris mitigation mechanism*
- *Higher CE investigation*




Setup configurations




Droplet transformation by pre-pulse


**Smaller fragments
Spread homogeneously**



Pre-pulse



**Observation
60 degree**




2:1

**True circle
looked like this
ellipse in this
configuration**

Droplet shooting scheme



Proper pre-pulse condition



a) without main-pulse laser



b) with main-pulse laser




Laser induced fluorescence (LIF) imaging for tin atom

Advantages

- Spectrally selective pumping and observation
- High sensitivity
- Cross sectional imaging with a sheet laser beam


Principle of LIF



Grotrian diagram for tin atom

Atom measurement by LIF - 2


Remaining atoms was estimated by subtracting
w/ CO2 vs w/o CO2 measurement



Results Summary

➤ Sn molecule measurement results

- ✓ **pre-pulse laser + CO2 laser irradiation** : ionized **93%** of Sn
- ✓ **Only pre-pulse laser irradiation** : ionized **3%** of Sn



**Experimental Condition:
 Same as proto machine**


		This time	Proto Condition
Repetition rate	Hz	10	100k



Conclusion of 10Hz device experiment

“Even with smaller than **20 μ m** droplet,

Ce=3.3% and **perfect vaporization** is simultaneously achieved”



-3.3% CE realized by 20 micron meter droplet

-pre-pulse is key to obtain higher CE

-This test was performed by 2 Hz operation

- CO₂ 100 mJ, with/without pre-pulse



Outline

1. Introduction

2. Engineering Test source

- **1st Generation (ETS) device: System experiment**
 - Operation Data
- **10Hz device: Critical issue experiment**
 - Vaporization experiment
 - Ionization experiment
 - Magnetic mitigation
 - Pre-pulse and high CE

3. HVM EUV light source

- **Product roadmap**
- **2nd Generation device: Development status**
 - Configuration
 - Latest status

4. Summary

EUV product roadmap


Power	Model	2009	2010	2011	2012	2013	2014	2015
500W	NXE:3300D					★		GL400E
350W	NXE:3300C				★		GL200E+	
250W	NXE:3300B			★		GL200E		
100W	Internal Use	ETS						

★ 1st source delivery

➤ **GL200E will be delivered to scanner manufacture at Mid Y2011.**



Clean power roadmap



EUV model		ETS	GL200E	GL200E+	GL400E
Drive laser power	kW	10	23	33	40
Conversion efficiency	%	3.0	5.0	5.0	6.0
C1 mirror collector angle	sr	5.5	5.5	5.5	5.5
efficiency*	%	74	74	74	74
C1 mirror reflectivity	%	(50)	57	57	57
Optical transmission	%	95	95	95	95
SPF (IR, DUV)	%	N/A**	62	62	62
Total EUV power (after SF	W	100	250	350	500






* Against hemisphere (Calculation base)

** w/o SPF





GL200E proto constructed at Hiratsuka facility




Main Amplifier performance



- Main amplifier characteristics : experimental results
 - ✓ ~10kW output achieved at 3kW input power
 - ✓ Good beam quality: $M^2 < 2.0$




Output beam profile



Pointing stability of CO2 laser w/ control, duty cycle 30%





Beam profile




Operation conditions	
Rep. rate [kHz]	100
Duty [%]	30
ON pls [pulse]	30,000
OFF time [msec]	700
Testing time [min]	120

Pointing stability of Pre-Pulse laser

w/ control, duty cycle 30%



Beam profile



Operation conditions	
Rep. rate [kHz]	100
Duty cycle [%]	30
ON pls [pulse]	30,000
OFF time [msec]	700
Testing time [min]	120


Droplet Generator for GL200E

Video

20 μ m, 10kHz




Slow image @nozzle



Synchronized image @plasma point

Position stability at 10 kHz




Sn droplet position variation at plasma point

Item	unit	target	result
position stability x	um	+/-20	7
position stability z	um	+/-20	18

- **Position stability is within specification for proto.**
- **Droplet generator on proto is working within spec.**

Scalability toward to 250W clean power

- 3.3% CE realized by 20 μm droplet
- It indicates ~100W clean power if operated at 100kHz*





Research and development scenery




First light of GL200E will come very soon !



Presentation on 02 March @SPIE 2011 ↑



3.11 Japan Earthquake



***We delayed 3 months.
Now recovering !***

***Real first EUV light ...
High power and debris free light
will come within a few weeks !***



KOMATSU



Outline

1. Introduction

2. Engineering Test source

- **1st Generation (ETS) device: System experiment**
 - Operation Data
- **10Hz device: Critical issue experiment**
 - Vaporization experiment
 - Ionization experiment
 - Magnetic mitigation
 - Pre-pulse and high CE

3. HVM EUV light source

- Product roadmap
- **2nd Generation device: Development status**
 - Configuration
 - Latest status

4. Summary

Summary

- **1st generation integrated setup LPP source (ETS) and 10 Hz device:**
 - One order smaller fragment (droplet size reduction from 60 μ m to 30 μ m) extends operation time to 7 hours under 20W(clean power @I/F, 5%duty) level operation.
 - 10Hz experiment proved debris mitigation concept experimentally. That is; proper pre-ionization and main ionization make >93% ionization. This technology enables clean light source with combination with magnetic field.
 - 10Hz experiment clarify CE (Conversion Efficiency) improvement, with <20 μ m droplet we found the region where Ce >3.3% and perfect vaporization are simultaneously possible.

- **2st generation LPP source (GL200E):**
 - Concept of design and outline is reported.
 - We already finished assembling and final engineering of components. The first light will be realized within a few weeks.

Acknowledgments

■ *Thanks to fund*

This work was partly supported by the New Energy and Industrial Technology Development Organization NEDO Japan, and Komatsu Ltd.

Gigaset's mission is to be the No. 1 provider of advanced technology and quality products, and to generate 100% profit.
We at Gigaset are all about being a team of professionals who are building a strong relationship of mutual trust. www.gigaset.com

